



## **Manual for the external Expression-Wheel:**

The Expression-Wheel has the same function as an expression-pedal.  
There is a TS- and a TRS-Version available.

The TS version has to be connected to the expression pedal jack of the device with a mono cable with 1/4" (6,3mm) plugs.  
It will work with Line 6, Eventide and Digitech devices.

The TRS version has to be connected to the expression pedal jack of the device with a stereo cable with 1/4" (6,3mm) plugs.  
It will work with Boss, Strymon, TC Electronic, Digitech, Electro Harmonix, JHS, Zoom and many other devices.

We hope, you`ve got the TS-Version for your Line 6 Stompbox Modeler or M-Series!

Workflow to guarantee full functionality!

- pull out the left/mono input-plug to switch off your unit
- turn the Expression-Wheel counter clockwise to its endposition and connect it with a mono cable (TS) with your Line 6 device
- reconnect the left/mono input-plug to power up your unit
- choose a saved preset and turn the Expression-Wheel clockwise to its endposition
- adjust one or more parameters of this chosen preset (all parameter except the model-selector can be adjusted)
- now, you can control infinitely variable between this two adjustments
- the next step is to save this preset by pressing the preset-footswitch until the LED is blinking
- without connected Expression-Wheel, your unit will work like the wheel is in the counter clockwise endposition

Have a lot of fun with your unit and thank you very much for the confidence you have placed in us!

Stay Tuned!